


FUELJECTOR DIMENSIONS



PART #	ALL STANDARD PIPE THREADS					
	A	B	C	D	E	F
No. 2	1-3/4"	4-1/2"	6-1/4"	3/8"	3/8"	1/2"
No. 3	2"	5-3/4"	7-3/4"	1/2"	1/2"	3/4"
No. 6	2- 1/2"	10"	12- 1/2"	1"	1"	1- 1/2"

AIR INSERT

FC-AI-2 - For Fueljector #2

FC-AI-3 - For Fueljector #3

FC-AI-6 - For Fueljector #6

